

RUMBLE CONCEPT

FENDER ELIMINATOR

RU36604

R1 2009-2011

WWW.RUMBLECONCEPT.COM

info@rumbleconcept.com

TEL: (514) 312-2134

FAX: (514) 312-2092

We at Rumble Concept encourage all installations to be performed by a **PROFESSIONAL**. If you choose to install this product yourself, please read all instructions and take all appropriate safety measures to ensure the proper and safe installation of your new Fender kit.

Before installation: our fender eliminator have been designed for modification purposes, we are not responsible for the use or misuse of any products, or verification of the local department of motor vehicles.

Included:

- 1x CY25760 Square Light
- 5x QU27946 Lock-nut
- 2x QU27948 Allen Bolt
- 2x FA35006 Flat Washer
- 2x AU27945 Nylon plate bolt/nut

****After any installations or modifications, the fender eliminator not returnable. We are not responsible for any damages to the part during the installation process, or to the bike (including the stock undertail part).**

- 1- Take off the rear seat.
- 2- Unplug signals and plate light in the trunk right in the center between the 2 seats(See pic.1)
- 3- Remove now the stock mudguard with the 3 Allen key bolt in the trunk, put them aside cause you will re-use them for your new fender.
- 4- Stick the provided plate light into your new fender bracket just below the R1 logo, bolt the plate holder to the bracket with 2 lock nuts and 2 black Allen M6 bolt all provided.
- 5- If you have signal lights (aftermarket ones) to install do it while fender is in your hands.
- 6- Now you can install your new fender with the 3 stock Allen bolt (See pic.2) along with the 3 lock nut and flat washers provided in the kit.
- 7- Drive your wires through the original passage and do your connections.
- 8- Put back the rear seat.
- 9- Your all set...have a great ride!!!

